



**PILA 360 GOAL POST
USER GUIDE
JAMISON PARK
SYNTHETIC FIELDS**

STEP - 1

OPENING THE STORAGE CAGE

- Unlock and fully open the storage cage gates
- Ensure the access path is clear before moving any goals
- Check that no nets are caught on the cage or other equipment before moving



STEP 2 –

REMOVING GOALS FROM STORAGE

- Move the goal using the metal frame/bars only.
- Push or pull the goal slowly and carefully.
- Never pull or lift the goal using the net.
- Ensure the net does not become snagged while removing the goal.

Important: The net is not a handle and must never be used to move the goal.



STEP 3 –

POSITIONING THE GOAL POSTS

- Move the goal to the required location on the synthetic field.
- Ensure the goal is positioned correctly before lowering.



Wheel Orientation: The transport wheels must

face outward, as shown in the image.

Incorrect wheel orientation may prevent the goal from operating correctly.



STEP 4 –

LOWERING THE GOAL INTO POSITION

- Stand beside the lowering handle.
- Press and hold the release button at the top of handle to disengage the latch.
- While holding the button, carefully lower the handle inward & continue lowering until the goal is fully secured in the playing position.
- Lower the wheel so the frame sits flat on the surface



Keep hands, fingers and feet clear of moving parts during lowering.



STEP 5 –

ANCHORING GOAL POSTS

- Ensure they are anchored during use and this is to comply with the Mandatory Australian Standards for Moveable Football Goalposts.
- Weighted sandbags as the anchoring method and these can take up to 20kg of sand each (split 10kg each side of the carry handle).
- To put these in place, just twist and remove the net clips, lay the bags over the frame and you can then slot the net clip back through the gap in the bag (under the handle) so that the nets remain attached to the base frame.



STEP 6 –

RAISING GOAL POSTS FOR TRANSPORT

- Ensure the wheels are positioned correctly before raising (see image)
- Pull handle, allow wheels to roll smoothly until it clicks into place



Wheel Orientation: The transport wheels must be placed as shown in the image. Incorrect wheel orientation may cause damage





GENERAL SAFETY REQUIREMENTS

DO

- ✓ Use the metal frame/bars to move goals.
- ✓ Move goals slowly and with care.
- ✓ Check nets are clear before moving.
- ✓ Use TWO people when moving goals where possible.

DO NOT

- ✗ Pull on the nets.
- ✗ Use the netting as a handle.
- ✗ Force goals through the cage opening.
- ✗ Allow nets to become trapped between goals or cage structures.

⚠ Important Notice

Damage caused by incorrect handling, including pulling on nets or improper operation of the lowering mechanism, may result in repair or replacement costs being charged to the user group.

